



## Installation Tools

### Pre-installation Check List

- Measure area to be installed, checking for proper material amount for coverage with a waste factor of 5-15% waste.
- Paint outlines where Porous Pave is to be installed to avoid wasting material. Also paint marks at quarter, half and three quarters to ensure proper Porous Pave coverage.
- Check base. Is the compaction at 95%? Is the void space in the stone base going to affect the amount of material? Refer to design section for base preparation
- Tools needed for installation:

- 8-12 cubic foot mortar mixer (not cement mixer!)
- 10 cubic foot wheelbarrow
- 2 flat shovels
- 2 come alongs
- 2 magnesium hand trowels
- 4' bull float
- Non-petroleum based vegetable oil for mixer and wheelbarrow
- Green Palmolive dish soap for bull float and trowels
- Bio-diesel (cleanup)
- Buckets
- Tarp
- 4 form boards measuring 4' long each, cut to desired thickness
- Screed board
- 2 garden sprayers (for oil and water)
- Latex gloves and fixed cuff rubber gloves
- Metal putty scrapers
- Hard bristle brushes



### Tools that may be needed depending on installation:

- Concrete saw
- Gas compactor
- Additional bull float
- Additional trowels
- Broom
- Back pack blower
- Mixer dolly
- 12" hand tamper
- Landscape rake
- Rags