

## **Curing Options for Elephant Armor®**

## 1. Best method is to Water Cure for at least 2 hours.

- a.) This can be accomplished by applying water soaked burlap or burlene.
- b.) It will provide the best hydration for the Elephant Armor® internal curing mechanism.
- c.) If Elephant Armor® has been tinted with color, powder or liquid, color intensity may be affected.

## 2. Second method is to spray on GST International Water Block.

- a.) Water Block should be sprayed on the Elephant Armor® after it has reached initial set as a curing agent.
- b.) Another application should be applied the next day in order to ensure water repellency and protection from corrosive environments.
- c.) If you are using Elephant Armor® for Decorative concrete overlays and will be applying stains or sealers, DO NOT use Water Block as a cure because it will block penetration and adhesion.

## 3. Third method is to spray on Elephant Armor® Cure.

- a.) Elephant Armor® Cure is a clear, dissipating resin water-based emulsion compound for use on freshly finished Elephant Armor® surfaces.
- b.) If you are using Elephant Armor® for Decorative concrete overlays and will be applying stains or sealers, DO NOT use Water Block as a cure because it will block penetration and adhesion.